

Congratulations on the purchase of your Show 'N' Fold™.

Owner's Manual

Includes:

Parts List

Assembly Instructions

Disassembly Instructions

Storage Instructions

Care Instructions

Warranty Information

Please read all of the information carefully and contact your distributor or supplier with any issues.



Parts List

Important: Before you begin please count and inspect all pieces.

- 1 - Panel Display (A)
- 4 - Header Display (B)
- 5 - Header Connector (C)
- 1 - Soft Carry Case (D)




Assembly Instructions




Step 1

Unfold outside panels to approximately 30° angles and set on tabletop.



Step 2

Line up the connector (C) with the groove on the edge of the display (A). Push down until the connector is sitting on top of the panel (A). Repeat on all panel edges.



Step 3

Line up the groove on the edge of the header (B) with connectors (C). Slide header (B) down until it rests on top of the center panel (A). Repeat for all headers.

Disassembly Instructions



Step 1

Remove header (B) and connectors (C) from display (A). Fold display (A) together in Z-shaped pattern, and lay it flat.

Storage Instructions



Place and store all components in soft carry case (D) and store in a cool dry place.

Care Instructions

Spot clean with a damp cloth.

Warranty Information

All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.